

Get temp - 1 - val * 10
Set set point - 2 - val * 10
Get setpoint - 4 (actual - working)

9600

} LPI_View

Set ramp rate - 95 (0 - ~~100~~ max) - val * 10 LPI_Setup

status - 5844 - Reset = 1 → manual
Run = 2
Hold = 4 } Pgm } → program_run

Circulation sw - 5953 - off = 0 } on/off use
on = 1 } manual

① Set to reset

②

Product ID - 122 - ^{val}9793
Instrument version no. - 107 - 1312 } Instrument (options)

Temperature Chamber - x26 Eurotherm
Controller